



KCA TOOL BOX TALK: Buried Utilities

There are often deadly hazards lurking underground on excavation sites. Rupturing or breaking underground utilities such as electrical power cables and pipelines can result in serious injuries or even death. Are you familiar with the steps you can take to avoid injury around buried utilities on a work site?

Signatures

- 1. _____
- 2. _____
- 3. _____
- 4. _____
- 5. _____
- 6. _____
- 7. _____
- 8. _____
- 9. _____
- 10. _____
- 11. _____
- 12. _____
- 13. _____
- 14. _____
- 15. _____
- 16. _____
- 17. _____
- 18. _____

Remember this:

- Before digging, look for paint or flag marking locations of electrical lines. Electrical lines should also have a warning device, such as a range control or limit. You should know how each is marked.

- Review marked-out areas. They may not be exact. If not sure call the utility company to verify before digging.

- Plan to dig by hand when working within 2 feet of a mark-out, to make sure you do not hit a utility line or conduit with heavy equipment. Ask your supervisor to identify the expert who will review the work area before work begins and as needed during your shift.

- When digging, look for signs of previous digging:
 - 1) Changes in soil types.
 - 2) Asphalt patches or depressions.
 - 3) Concrete, plastic, or gravel.

For more information visit OSHA REGULATIONS: 1926.651; 1926.652; 1926.1408